# Command 8 Guide

### for Pro Tools TDM and LE Systems on Windows or Macintosh

### **Digidesign**

2001 Junipero Serra Boulevard Daly City, CA 94014-3886 USA

tel: 650·731·6300 fax: 650·731·6399

#### Technical Support (USA)

tel: 650·731·6100 fax: 650·731·6384

#### **Product Information (USA)**

tel: 650·731·6102 tel: 800·333·2137

#### **International Offices**

Visit the Digidesign Web site for contact information

#### **Web Site**

www.digidesign.com



#### Copyright

This guide is copyrighted ©2004 by Digidesign, a division of Avid Technology, Inc. (hereafter "Digidesign"), with all rights reserved. Under copyright laws, this guide may not be duplicated in whole or in part without the written consent of Digidesign.

DIGIDESIGN, AVID and PRO TOOLS are trademarks or registered trademarks of Digidesign and/or Avid Technology, Inc. All other trademarks are the property of their respective owners.

Product features, specifications, system requirements and availability are subject to change without notice.

PN 932012395-00 REV A 04/04

#### **DECLARATION OF CONFORMITY**

We Digidesign,

3401-A Hillview Avenue

Palo Alto, California 94304-1348, USA

650-842-7900

declare under our sole responsibility that the product Command|8

complies with Part 15 of FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following

- · Reorient or locate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



## Command 8




Any modifications to the unit, unless expressly approved by Digidesign, could void the user's authority to operate the equipment.

#### **Canadian Compliance Statement:**

This Class B digital apparatus complies with Canadian ICES-003

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

#### **Australian Compliance**



#### **European Compliance**



## contents

Chapter 1. Introduction			
Comman	d   8 Features	1	
Included	with Command   8	1	
System F	equirements and Compatibility	2	
About wy	w.digidesign.com	2	
MIDI Con	trol Surface Terms	3	
About Th	s Guide	3	
Chapter 2. Inst	alling and Configuring Command 8	5	
Before Y	u Begin!	5	
Installati	on Guidelines	5	
Example	Setups	6	
Comman	d   8 Back Panel	8	
Connecti	ng Command   8 to Pro Tools and Your Computer	8	
Installing	Software for Command   8	9	
Connecti	ng Analog Audio for Monitoring	1	
Connecti	ng a Footswitch	2	
Connecti	ng MIDI Devices	2	
Configuri	ng MIDI	3	
Enabling	Command   8 in Pro Tools	4	
Commun	ication Test	6	
Troubles	ooting	6	

Chapte	r 3. Command 8 Overview	19
	Command   8 Operating Modes	19
	Command   8 Control Surface	20
	LCD Display	21
	Fader Strips	22
	Console and Channel View Controls for Pan, Sends, and Inserts	24
	Transport, Navigation, and Zoom Controls	27
	Monitoring Controls	29
	Modifiers Switches	29
	Standalone Switch	29
	USB and MIDI Activity LEDs	30
Chapte	r 4. Using Command 8 with Pro Tools	31
	Controlling the Transport	31
	Undo and Redo	31
	Navigating	32
	Recording	34
	Sends	38
	Plug-Ins and Inserts	39
	Software Synths and Rewire Applications	43
Chapte	r 5. Using Stand-Alone Mode	45
	Overview of Stand-Alone Mode	45
	Stand-Alone Mode QuickStart	46
	Selecting Stand-Alone Mode	46
	Mapping	47
	Editing MIDI Maps	49
	Presets to Save and Recall Mans	51

Appen	idix A. Utility Functions
	Accessing Utility Mode
	Fader Tests. 56
	LED Tests
	LCD Display Test
	Switch Test. 57
	Encoder Test
Index	59

### chapter 1

### Introduction

Welcome to Command 8, a control surface for developed in collaboration between Digidesign and Focusrite. Command 8 is a compact, and flexible control surface for Pro Tools TDM and LE systems, and supported Avid systems.

### **Command** 8 Features

Some of the main features of Command 8 include:

- Eight fader strips, each featuring a motorized, touch-sensitive fader, rotary encoder, LEDs, and Solo, Mute, and Channel Select switches.
- Analog monitoring section with output and level control for mains and headphones. Two pairs of analog inputs are provided, one for your main mix from Pro Tools, and one for alternate sources (such as CD, Mini-Disc, and DAT players).
- One MIDI In port and two MIDI Out ports providing 16 channels of MIDI input, and 32 channels of MIDI output.
- USB port for direct USB MIDI communication with Pro Tools.
- Large, bright LCD for data display.
- 1/4-inch Punch In port for footswitch control of recording.
- Transport controls and mode switches.
- Windows switches for Pro Tools display.

- Navigation and Zoom controls.
- Tactile control of track volume, pan, send level, send pan, and record status, as well as PRE (Digidesign mic preamplifier) gain.
- Fast and convenient access to sends, inserts, plug-in pages, pan settings, and other track functions.
- Five Function keys to access Utility, Fader Mute, and MIDI mapping functions.
- AC power supply designed specifically for Command 8.
- Stand-alone mode with snapshot save and recall, lets you use Command 8 to control any device that supports MIDI Continuous Controller messages. Custom MIDI mapping can be programmed as needed, and up to eight snapshots can be saved locally in Command|8.

### **Included with Command**|8

Items included with Command 8 are:

- Command|8 control surface
- Command|8 Guide
- USB cable
- Power adapter
- Pro Tools software for Command 8
- · Registration card

### **System Requirements and Compatibility**

Command|8 can be used with any supported Pro Tools TDM or Pro Tools LE system for tactile control of recording and mixing. Command|8 can also be used in Stand-alone mode and mapped to control most digital audio workstations or devices that support MIDI.

Digidesign can only assure compatibility and provide support for hardware and software it has tested and approved.

For a list of Digidesign-qualified computers, operating systems, and third-party devices, refer to the latest compatibility information on the Digidesign Web site (www.digidesign.com/compato).

#### **Digidesign Registration**

Make sure to complete and return the registration card included with Command 8. This is your best way to receive news of updates and other Digidesign product information. (See also "About www.digidesign.com" on page 2.)

### **About www.digidesign.com**

The Digidesign Web site (www.digidesign.com) is your best source for information to help you get the most out of your Pro Tools system. The following are just a few of the services and features available.

**Support** Contact Digidesign Technical Support or Customer Service; download software updates and the latest online manuals: browse the Compatibility documents for system requirements; search the online Answerbase or join the worldwide Pro Tools community on the Digidesign User Conference.

Training and Education Study on your own using courses available online or find out how you can learn in a classroom setting at a certified Pro Tools training center.

Products and Developers Learn about Digidesign products; download demo software or learn about our Development Partners and their plugins, applications, and hardware.

News and Events Get the latest news from Digidesign or sign up for a Pro Tools demo.

To learn more about these and other resources available from Digidesign, visit our Web site (www.digidesign.com).

### **MIDI Control Surface Terms**

Here are a few terms that apply to the use of a MIDI control surface with Pro Tools.

**Bank** A group of similar controls (such as faders, rotary controls, or switches) that are arranged in discrete channel strips. With Command 8, you can operate one bank of controls at a time.

Bank Size or Bank Width Corresponds to the number of fader strips on your MIDI control surface. Command|8 has eight fader strips.

**Bank Swap** The process by which you switch control from one on-screen bank of channel strip faders to another.

**Global Controls** Controls that perform single functions that never change. For example, the transport switches affect all tracks, and do not change when you switch banks.

Control Surface Focus When you select a track, send, plug-in, or output window for editing on a control surface, it becomes the control surface focus. This distinction is indicated by a colored outline surrounding the top panel of the window in Pro Tools.

### **About This Guide**

This guide assumes you have already installed Pro Tools, and that you already have an understanding of its features and operating conventions as explained in the Pro Tools Reference Guide.

#### **Conventions Used in This Guide**

This guide uses the following conventions to indicate Pro Tools on-screen menu choices and key commands:

Convention	Action	
File > Save Session	Choose Save Session from the File menu	
Control+N	Hold down the Control key and press the N key	
Control-click	Hold down the Control key and click the mouse button	
Right-click (Windows)	Click with the right mouse button	

Command 8 features a Modifiers section that provides the following modifier-key equivalents:

Command   8 Modifier	Modifier Key Equivalents	
	Windows	Macintosh
SHIFT/ADD	Shift	Shift
OPT(ALT)/ALL	Alt	Option
光/(CTL)	Control	Command
CTL/CLUTCH	Start	Control


The following symbols are used to highlight important information:




User Tips are helpful hints for getting the most out of Command 8.



**A** Warnings include information that could affect the performance of Command|8 hardware or Pro Tools session data.





## chapter 2

## Installing and Configuring Command 8

This chapter explains how to install and configure Command 8.

### **Before You Begin**

#### Before installing Command 8 for use with **Pro Tools:**

■ Make sure Pro Tools is correctly installed and operating before installing Command 8. Pro Tools software includes software for Command 8, installed by default as part of the Easy Install option.



**A** If you did a Custom Install of Pro Tools, you may need to reinsert your Pro Tools Installer CD while installing Command 8, as noted later in this chapter.

### Installation Guidelines

Unpack Command | 8 from its shipping container, being careful not to lose any included components or information sheets. Read all included material for any updates or other important information.

Place Command 8 on a flat surface near your computer monitor. Make sure not to block the back, sides, or front of Command|8 to maintain proper ventilation. If mounting Command 8 in studio furniture, be sure to leave adequate space around the vents at the rear and front.

When installing Command 8, be aware of the following guidelines and options:

- Pro Tools does not support the use of more than one Command 8 at a time. In other words, two or more Command | 8 units cannot be enabled simultaneously in Pro Tools.
- Command|8 must be the only MIDI control surface enabled within Pro Tools.
- Command 8 can be used in combination with non-MIDI control surfaces with some limitations. See "Command|8 with Other Control Surfaces" on page 7 for more information.
- Command 8 can also be used as a stand-alone MIDI control surface to control software synths and Rewire applications, supported Avid systems, and any device that supports MIDI Continuous Controller (CC) communication. See Chapter 5, "Using Stand-Alone Mode" for installation and operational information about stand-alone use.

### **Example Setups**

Figure 1 shows Command|8 connected for use with Pro Tools, acting as a control surface, MIDI interface, and monitor controller.

### **Command 8 with Pro Tools Setup**




Figure 1. Connecting Command | 8 as a Pro Tools control surface, MIDI interface, and monitor controller

In this setup, the Command|8 USB port is connected to the host computer. This provides the communication necessary for Command|8 faders, encoders, and switches to control Pro Tools sessions (as well as compatible Rewire applications running within the Pro Tools mix environment).

A MIDI keyboard and sound module are connected to the Command|8 MIDI In and MIDI Out ports. Because Command|8 utilizes USB MIDI communication, you can use all three MIDI ports to integrate MIDI keyboard and other controllers, sound modules, and samplers into your Pro Tools sessions.

Analog audio is from Pro Tools is sent from an audio interface (such as an HD I/O, Digi 002 Rack, or Mbox) to the Command|8 Main Monitor inputs. The Command|8 Speaker Outputs are connected to powered monitors for control room monitoring. An additional stereo source is also connected to the Command|8 External Source Inputs. The Control Room and Headphone controls let you select between input sources (Main, or External), with control room Level, Mono, and Mute control. The Headphone output follows the control room input source selection, with its own separate level control that only affects the top panel Headphone port.

### **Command** 8 with Other Control Surfaces

#### Digi 002 and Command|8

When used as a MIDI control surface with supported Digi 002 and Digi 002 Rack systems, Command 8 faders function as additional faders (9–16, when left justified). Figure 2 shows fader mapping when Command|8 is used with a Digi 002. (Plug-ins cannot be edited on Command|8 when used with a Digi 002.) Use Command 8 for expanded fader control, or remote transport and monitoring.



Figure 2. Digi 002 (or Digi 002R) and Command 8 fader mapping

#### ProControl or Control|24 and Command|8

Command 8 can be used simultaneously with ProControl or Control 24 as a remote Transport for isolation rooms, drum booths, and other locations for remote control of play and record functions. When used with ProControl or Control [24, Command]8 faders overlap (duplicate) the left-most eight faders currently banked on Control 24.

Figure 3 shows basic connections when adding Command 8 to a Control 24 system (connections for ProControl would be similar).




Figure 3. Control | 24-based Pro Tools system with Command | 8 as a remote transport and monitor controller

### **Command** 8 Back Panel

The figure below shows the Command |8 back panel connectors and switches.




Figure 4. Command 8 rear panel

# Connecting Command 8 to Pro Tools and Your Computer

This section lists the basic steps required to connect Command 8 to Pro Tools. Detailed instructions for each step can be found later in this chapter.

## Installing Command 8 for Pro Tools involves the following:

- **1** Connect AC power (see "Connecting AC Power" on page 9).
- **2** Connect USB ("Connecting USB" on page 9).
- **3** Install Command|8 software (see "Installing Software for Command|8" on page 9).
- **4** Connect audio for monitoring (see "Connecting Analog Audio for Monitoring" on page 11).
- **5** Connect a footswitch for punch recording (see "Connecting a Footswitch" on page 12).

- **6** Connect MIDI devices (see "Connecting MIDI Devices" on page 12).
- **7** Configure MIDI (see "Configuring MIDI" on page 13).
- **8** Configure Pro Tools (see "Enabling Command|8 in Pro Tools" on page 14).

For complete instructions to use Command 8 in stand-alone mode, see Chapter 5, "Using Stand-Alone Mode."

### **Connecting AC Power**

Connect power using the included power supplv cable. Command|8 is not powered through its USB connection.



The Command\8 power supply is available in three configurations (90– 120v for Japan and USA, 220-230 Europe, and 220 for UK); if travelling or ordering a replacement unit, be sure to specify the country in which vou plan to use Command 8.

#### To connect power to Command 8:

- **1** Make sure the power switch is in the Off position (down).
- 2 Connect the threaded end of the included power supply cable to the Power socket on the Command | 8 rear panel. Use two hands, one to insert and guide the plug in the socket, and the other to ensure that the ring threads smoothly and seats securely on the socket.



**A** Only use the included power supply cable to connect Command 8 power. Additional power supplies are available from your Digidesign dealer. Use of any other cable or power supply may damage your unit.

**3** Plug the power supply into an available AC power outlet.



The Command 8 analog output section automatically mutes during power-up and power-down.

### **Connecting USB**

Command 8 communicates with Pro Tools through a USB connection to the host computer. Command 8 does not require a powered USB connection. All power is supplied through its AC connection.

#### To connect USB:

- 1 Start up your computer, logging in as Administrator.
- 2 Make sure Command 8 is powered on (see "Connecting AC Power" on page 9 for more information).
- 3 Connect one end of the included USB cable to the USB port on the rear panel of Command 8.
- 4 Connect the other end of the USB cable to an available USB port on your computer.
- **5** When prompted to install software, see the appropriate Windows or Macintosh installation instructions that follow.

### **Installing Software for** Command 8

Command 8 software is included on your Pro Tools Installer CD-ROM, and this software is required to use Command|8 with Pro Tools.



On Macintosh systems that only intend to use Command|8 in standalone mode, no software installation is required (Command | 8 does not require a custom driver on Macintosh systems using standalone mode).

### **Windows Software for Command 8**

The Pro Tools Installer includes the option "Command8 Controller and Driver."

If you enabled the Command |8 option when installing Pro Tools, all software required by Command 8 is installed automatically.

If you installed Pro Tools and did not select this option, first use your Pro Tools Installer CD-ROM to install the required Command 8 software. If Pro Tools was already installed, be sure to Modify your installation. (See the Getting Started guide that came with your Pro Tools system for complete Pro Tools software installation information.)

#### To install Command 8 software on Windows:

- **1** Connect power and USB as instructed in "Connecting AC Power" on page 9 and "Connecting USB" on page 9.
- 2 Make sure you have already installed Pro Tools, including the Command | 8 options, and restarted your computer. Start up your computer with Administrator privileges.
- 3 When the Found New Hardware Wizard appears, ignore the prompt — leave the Found New Hardware Wizard dialog open on screen.
- 4 Insert the Pro Tools Installer into your CD-ROM drive.
- **5** Launch the Pro Tools Installer, and choose to Modify the installed components.
- 6 When prompted, select the Command8 Controller and Driver option.
- 7 When asked about driver signing, click Continue.
- 8 Click Finish.
- 9 Restart your computer.

#### **USB Ports and Command** 8 Software

If you move your Command |8 USB cable to a different USB port on your computer, you must reinstall the Command |8 software.



The Pro Tools Installer creates a Command8 folder in your Digidesign directory. This folder contains copies of all the software you need to reinstall Command 8. *Use the contents of this folder if your* Pro Tools Installer is not available.

### Macintosh Software for Command 8

#### To install Command 8 software on Macintosh:

- 1 Start up your computer using your Administrator account.
- 2 Check to make sure the Command 8 Personality file is installed (Applications / Digidesign / Controllers/Command|8).
- **3** If it is not, insert the Pro Tools Installer into your CD-ROM drive and launch the Install Pro Tools application. Choose Custom Install and select the Controllers option to install all Controller Personality files.

### Firmware for Command 8

Command 8 can be updated for new features and capabilities by updating its firmware. Instructions for updating Command 8 firmware can be found in the Read Me document that accompanies each release of updated firmware.

Check the Digidesign Web site (www.digidesign.com) for news of updated Command |8 firmware, as well as download and installation instructions.



A firmware updater application and associated Read Me file are included as part of the Command 8 software package.

### **Connecting Analog Audio for Monitoring**

Analog audio connections let you use Command|8 for control room and headphone monitoring. Analog audio connections are not required for Command|8 to control Pro Tools mixing functions.



The Command 8 analog audio features are for monitoring only. Command 8 is not an audio interface for Pro Tools systems.

### **Monitoring Overview**

Command|8 provides the following analog audio connectors.

#### Input

• Two pairs of balanced, TRS inputs, labelled Main and Ext Source on the rear panel of Command | 8. Each input pair is switchable between -10 dBV or +4 dBu operation.

#### Output

- Two channels of balanced, TRS output to connect to powered speakers, a monitor amplifier or other monitor equipment. Outputs are switchable between -10 dBV or +4 dBu.
- One stereo Headphone output, which mirrors the currently selected monitor input source (see "Monitoring Controls" on page 29).

### **Input Connections**

#### To monitor Pro Tools through Command 8:

- 1 Connect your Pro Tools stereo mix outputs (usually Outputs 1–2) to the Command 8 Main Left and Right monitor inputs on the back panel. The Main inputs are balanced, TRS inputs.
- 2 Configure Main inputs for -10 dBV or +4 dBu operation, as appropriate, using the button between the Left and Right inputs.

#### To be able to monitor another stereo device through Command 8:

- **1** Connect the analog outputs of a CD, DAT, or other device to the Ext Source Left and Right inputs on the back panel.
- 2 Configure the Ext Source inputs for -10 dBV or +4 dBu operation, as appropriate, using the button between the Left and Right inputs.

### **Output Connections**

#### To connect Command 8 to your monitoring system:

**1** Be sure to mute, turn down, or power off your monitors or monitoring system.



The Command 8 analog output section automatically mutes during power-up and power-down.

- 2 On the Command 8 top surface, turn the Control Room Level knob all the way down.
- 3 Configure the Command 8 Main outputs for -10 dBV or +4 dBu operation, as appropriate, using the -10/+4 button between the two output ports on the back panel.

4 Connect the Main Left and Right outputs on the Command|8 back panel to the inputs of powered monitors, a monitor amplifier, or other monitor equipment.

### **Headphones**

#### To connect headphones:

■ Connect a pair of headphones to the Headphones port next to the Control Room section.

The Headphones Level knob controls headphone level only. This Headphone output is designed to power a single pair of standard-quality headphones, and is not designed to drive powered speakers or headphone distribution amplifiers.

### **Connecting a Footswitch**

The Punch In connector on the Command|8 rear panel supports footswitch control of Track-Punch and QuickPunch audio punch-in and punch-out recording features. Both continuous on/continuous off and instantaneous on/off pedals with a 1/4-inch TRS connector are supported.

#### To connect a footswitch:

■ Connect a footswitch to the Punch In connector.

### **Connecting MIDI Devices**

Command | 8 provides 16 channels of MIDI input and 32 channels of MIDI output through the MIDI IN 1, MIDI OUT 1, and MIDI OUT 2 connectors on the back panel. The connectors accept standard 5-pin MIDI cables.

Command 8 driver software, installed when you install Pro Tools (or stand-alone) software, is required for MIDI communication to function. These drivers are recognized by Windows Multimedia and the Device Manager (Windows), and by AMS (Macintosh).

Use the following instructions to integrate Command | 8 with other MIDI equipment.

#### To connect MIDI devices to Command 8 for **Pro Tools:**

- **1** Using standard 5-pin MIDI cables, connect the MIDI Out port of a MIDI keyboard or other MIDI device to the MIDI In 1 port of your Command|8, and connect the MIDI In port of your MIDI device or controller to MIDI Out 1 port of your Command 8.
- 2 Connect MIDI Out 2 of Command 8 to the MIDI In port of an additional MIDI device (such as a groove box or sound module).
- 3 To monitor or record the audio output of your MIDI devices within Pro Tools, connect the audio outputs of your devices to available audio inputs on your Pro Tools audio interface.

#### **USB MIDI Communication and Command**|8 **Operating Modes**

When connected to Pro Tools through USB, Command|8 is recognized as a MIDI Control Surface and MIDI interface (the Command|8 MIDI connectors are available as MIDI In and Out ports).

### **Configuring MIDI**

After connecting Command 8 and installing its software, you may want to update your MIDI system. This may be necessary when using Command|8 as both a control surface and as a MIDI interface.

- On Windows, Command 8 should be automatically recognized once Pro Tools and Command 8 software is installed and the computer is restarted. If necessary, configure the Device Manager to enable or troubleshoot USB MIDI devices and ports. (See "Windows MIDI Troubleshooting" on page 17.)
- On Macintosh, configure AMS to make Command 8 MIDI ports and devices attached to them available in Pro Tools (see "Configuring AMS" on page 13).

### **Configuring Windows Device** Manager

(Windows Only)

In Windows, make sure you have enabled the USB port for Command | 8 using the Device Manager. Make sure you have installed all necessary Command | 8 software. See "Installing Software for Command 8" on page 9 for instructions.

### **Configuring AMS**

(Macintosh Only)

On Macintosh systems, use AMS to check MIDI communication and update your AMS setup.


#### To update AMS for Command 8:

1 Make sure power and USB are connected as instructed. (See "Connecting Command|8 to Pro Tools and Your Computer" on page 8.)

- 2 Make sure you have connected any additional MIDI keyboards or sound modules to the Command | 8 5-pin MIDI ports on the back panel. (See "Connecting MIDI Devices" on page 12.)
- **3** Make sure you have installed the most recent version of Pro Tools and the included Command|8 software. (See "Installing Software for Command 8" on page 9.)
- 4 Launch AMS.
- **5** Make sure that Command 8 is recognized, is online, and that its three ports are available in AMS.
- 6 Configure AMS for any devices attached to the Command | 8 MIDI In and Out ports by connecting their device icons to the appropriate Command 8 ports.

Do not connect any AMS devices to Command 8 Port 1. Port 1 is reserved for Command|8-to-Pro Tools control surface communication.

The following shows an example AMS Setup for Command 8 and Pro Tools, with two MIDI devices attached to the back panel MIDI ports of the Command 8. Note how Command 8 port 1 is not assigned to any external devices.



The following table shows how AMS lists Command | 8 MIDI ports:

#### Command | 8 port equivalents in AMS

AMS (in/out)	Command   8 back panel ports
Port 1	none (reserved for control surface communication via USB MIDI)
Port 2	Midi In 1, Midi Out 1
Port 3	Midi Out 2

**7** Save and close your updated AMS setup.



See the Getting Started Guide that came with your system, and your Apple documentation, for more information about AMS.

### **Enabling Command 8 in Pro Tools**

#### To enable Command 8 in Pro Tools:

- **1** Make sure your computer, Pro Tools hardware, and Command |8 are powered on and operating correctly.
- 2 Launch Pro Tools.
- **3** Choose Setups > Peripherals and open the MIDI Controllers window.
- 4 Choose Command 8 from the Type pop-up menu.

5 Choose C|8 Surface (Windows) or Port 1 (Macintosh) in the Receive From and Send To selectors.



Choosing the a port (Windows)



Choosing a port (Macintosh)



MIDI Out1 and MIDI Out2 are the back panel 5-pin MIDI connectors. C8 Surface (Windows) and Command 8 Port 1 (Macintosh) represent the USB MIDI connection between Pro Tools and Command 8. For more information, see "Configuring MIDI" on page 13.



**△** On Macintosh, Command 8 Port 1 must only be used for control surface communication. If using Command 8 as a MIDI interface as well as a control surface, check all MIDI tracks to make sure they are assigned to Port 2, or Port 3. Do not assign MIDI tracks to Port 1.

6 If Command 8 choices are not available, click Cancel, then check all USB, MIDI, and power connections to and from Command 8. Make sure all software is installed and try again.

**7** Click OK.

### **Configuring Command** 8 MIDI **Interface Connections**

The following example shows how to configure Pro Tools to integrate a MIDI device connected to Command | 8 MIDI ports. This example shows how the Digidesign PRE microphone preamp is connected to Command 8 and configured in Pro Tools for MIDI remote control of channel gain.



For more information, see "Controlling PRE" on page 37).

#### To enable a PRE connected to Command 8:

- 1 Make sure you have connected MIDI correctly between PRE and the MIDI In and MIDI OUT 1 ports on Command 8.
- 2 Make sure Command 8 is installed and has been enabled in Pro Tools (see "Enabling Command 8 in Pro Tools" on page 14).
- 3 Choose Peripherals > Setup, and open the Mic Preamp page.
- 4 Configure the Mic Preamp window by doing the following (see the Digidesign PRE Guide for details).
- On Windows, choose Command 8 MIDI Out and In 1 for the Receive From and Send To ports.
- On Macintosh, choose Port 2 Out and In.
- For each port, choose the MIDI channel appropriate for your PRE and channel.



Enabling a PRE connected to Command 8 MIDI ports



PRE defaults to MIDI channel 1, but can be configured to communicate on any of the 16 available MIDI channels. Check your unit (using the front panel MIDI CHAN/IO switch) if you are unsure.

5 Click OK.


### **Enabling Input Devices**

(Macintosh Only)

On Macintosh, you must enable the MIDI control surface as an input device in Pro Tools.

#### To enable an input device:

- **1** Choose MIDI > Input Devices.
- 2 Select the Command 8 MIDI control surface.
- 3 Click OK.



When you add a device in Apple Audio MIDI Setup while Pro Tools is running, it will be automatically enabled as an input device. If you want to prevent MIDI data from a control surface reaching Pro Tools, you can disable a control surface as an input device.



For more information on recording MIDI and enabling input devices, refer to the Pro Tools Reference Guide.

### **Communication Test**

#### To test Command 8 communication with **Pro Tools:**

- 1 With Pro Tools running, make sure Command 8 is enabled and recognized by Pro Tools (see "Enabling Command|8 in Pro Tools" on page 14).
- 2 Open a session.
- 3 Make sure the Control Room LEVEL knob is all the way down (off).
- 4 Press PLAY on Command 8. Pro Tools starts playing.
- 5 Move a fader or knob on Command 8, and the corresponding on-screen control should move.

#### To set basic Pro Tools monitoring levels:

- 1 While still playing back, check that Ext Sources is dark (not enabled) in the Control Room monitor section.
- 2 Turn the Control Room LEVEL or Headphone LEVEL to a desirable listening level.
- 3 Continue adjusting levels, and press STOP to stop playback.



The Control Room section is explained in detail in Chapter 3, "Command|8 Overview."

### **Troubleshooting**

If your system does not seem to be responding correctly, check all MIDI connections and settings. If there is still a problem, repeat the installation and configuration steps.

Once enabled in Peripherals, Command 8 will be available every time you launch Pro Tools until you deselect it in the MIDI Control Surfaces window, or communication is lost.

#### Lost Communication

To re-establish communication, repeat the instructions in "Enabling Command|8 in Pro Tools" on page 14. If problems persist, check your MIDI configuration (see "Configuring MIDI" on page 13).

### **Lost Communication after Reconnecting Command** 8

On Windows, you must reinstall the Command|8 software if you move Command|8 to a different USB port. The software installation only installs software to the USB port to which the Command 8 is connected. If you move Command 8 to a different port and Pro Tools cannot communicate, reinstall software and try again (see "Installing Software for Command|8" on page 9).

### **Incomplete or Eratic** Communication

If Command |8 seems to be communicating inconsistently, or incompletely, try the following.

#### To refresh and reinitialize Command 8 in Pro Tools:

- **1** Choose Setups > Peripherals > MIDI Control Surfaces.
- 2 In the Device selector, choose None and click OK.
- 3 On Command 8, make sure the Standalone switch is completely off (not flashing or lit).
- 4 Choose Setups > Peripherals > MIDI Control Surfaces, and repeat the steps to enable Command 8 in Pro Tools (see "Enabling Command 8 in Pro Tools" on page 14).

### **Windows MIDI Troubleshooting**

If Command 8 is not recognized by Windows XP after installing its software from the Pro Tools Installer CD-ROM, it may indicate that the maximum number of MIDI driver entries in your registry (10) has been exceeded. In most cases, at least one duplicate or obsolete entry can be deleted to accommodate Command|8 USB communication by doing the following:

#### To check the number of MIDI drivers in your registry:

- 1 Choose Start > Run.
- 2 Run "regedit" to display the Windows registry editor.
- **3** Expand the HKEY\_LOCAL\_MACHINE tab.
- **4** Expand the SOFTWARE tab.
- **5** Expand the Microsoft tab.
- 6 Expand the Windows NT tab.

- 7 Click the Current Version tab.
- **8** Choose Drivers.32 to display the Drivers.32 tab.
- **9** Look at the entries in the right hand panel for MIDI entries listed as "midi" "midi1" and so on.
- 10 If the highest "midi" entry is 8, then no action is required. (Skip the following steps and repeat the software installation steps in "Windows Software for Command|8" on page 10 to see if problems persist.)

– or –

If there is an entry for "midi9" then the maximum number of MIDI drivers has been reached and at least one must be removed in order for the Command 8 driver installation to succeed.

#### To update the number of MIDI drivers in your registry:

- 1 Identify any identical (duplicate) entries and delete the one with the highest entry number. For example, if there are "rddv1009.dll" entries in midi3 and midi4, delete the higher one (midi4).
- 2 Identify any unused or obsolete entries and delete them.
- **3** Repeat the software installation instructions (see "Installing Software for Command|8" on page 9).

### chapter 3

## **Command** 8 Overview

This chapter introduces you to the Command 8 control surface and its main control sections, as well as describing the different operating modes in which Command 8 can be used.

### **Command 8 Operating Modes**

When powered on, Command | 8 will be in Standby mode. Command 8 also has two operating modes: Pro Tools mode, or Stand-alone mode.

#### **Standby Mode**

Command 8 is in Standby mode when it is first powered on, waiting for you to either launch Pro Tools (or a supported Avid system) or enter Stand-alone mode.

#### **Pro Tools Mode**

When connected and powered on, Command 8 enters Pro Tools mode whenever you launch Pro Tools. With a session open while in Pro Tools mode, Command 8 faders, transport switches, rotary knobs, and switches directly control Pro Tools sessions and tracks. Command 8 MIDI ports can be used as you would those on a standard MIDI interface.

#### **Avid Mode**

When connected and powered on, Command 8 enters Avid mode whenever you launch a supported version of Avid Symphony, Avid Media Composer, Avid Xpress, or Avid Xpress Pro. Faders automatically map to the Automation Gain Tool channels 1-8; Mute switches map to Track On controls; Solo maps directly to solo (Automation Gain Tool); Channel Select maps to track selection (Automation Gain Tool); and the Channel Mode switches map to track Snap Record. See your Avid documentation for more information on these features.

#### **Stand-Alone Mode**

With Command 8 in Stand-alone mode, the unit becomes a MIDI control surface, MIDI interface, and analog monitoring controller that operates independently from Pro Tools.

Command 8 can be toggled back and forth between Pro Tools and Stand-alone modes at any time, providing tactile control of Pro Tools as well as software synthesizers, Rewire applications, and other devices in use in your sessions.



For more information, see Chapter 5, "Using Stand-Alone Mode."

## **Command|8 Control Surface**

Figure 1 identifies each of the main Command 8 control sections.




Figure 1. Command | 8 control sections

### **LCD Display**

The LCD is a large, two-row display that shows up to six characters per fader strip. The LCD is where track names, inserts, sends, parameter names, values, session time, and text messages are displayed.

The LCD displays track, insert, send, and other parameters depending on the current view, as selected by the Channel/Console switches. For example, in Home view, the LCD displays track name in the lower row, while the upper row displays pan at the far left and the Timeline counter at the upper right.

#### **Views in Pro Tools Mode**

When Command 8 is used with Pro Tools, many of its controls perform more than one function, depending on which of three primary views you are in: Home View, Console View or Channel View.

#### **Home View**

Home View is the default view in Pro Tools that you see when you first open a session. Home view is functionally identical to Console View with the Pan controls displayed.

#### **Console View**

Command | 8 is in Console View when any of the Console View selectors Pan. Send. or Insert is lit in the Console View area.

Console View lets you toggle Command 8 to show pan position, send assignments or insert assignments for all channels on the control surface. Think of Console View as a global view of a given control (pan, send, or insert) on each channel. (See "Console View Switches" on page 24.)



When you first open a Pro Tools session, Command 8 is in Console View with the Pan switch lit. This default view is also known as "Home View."


#### **Channel View**

Command 8 is in Channel View when any of the Channel View selectors (EQ, Dynamics, Insert or Pan/Send/PRE) is lit in the Channel View area below the LED display.

Channel View lets you display plug-in assignments, insert names, or send assignments at the same time. You can think of Channel View as a way to quickly see which channels have EQ, Dynamics, Inserts, and sends. (See "Channel View Switches" on page 25.)

### **Fader Strips**

Command | 8 provides eight fader strips with identical controls.



Fader strip

#### **Channel Faders**

Each channel has its own 100 mm, servo-driven. touch-sensitive, motorized fader for controlling levels of audio and MIDI tracks, Auxiliary Inputs, and Master Faders. In Flip mode, the faders control send levels and plug-in parameters. For more information about Fader Gain (+12 dB and +6 dB sessions) see the Pro Tools Reference Guide.

#### **Fader Mute**

Because Command 8 faders are motorized, they move to follow automation when playing back and recording (when the track is set to an automation read or write mode, and not Off). During critical listening passes, the sound of the fader

motors and their automated movements may be distracting. You can temporarily shut off (or mute) motorized fader movement using the F4/Fader Mute switch.

#### To mute faders:

- **1** Press F4/Fader Mute. While enabled, faders park and do not respond to touching or movement. Previously recorded automation continues to affect playback; the faders are simply "clutched" or disengaged from reading.
- 2 Press F4/Fader Mute again to re-engage faders and unmute them.

#### **Channel Solo and Mute Switches**

Each channel has Solo and Mute switches, located above the fader. These switches show the Pro Tools Solo and Mute status for each track. When a track is soloed, the Mute switches on other tracks in the session flash. When a track is muted, the Mute switch is lit continuously.

The Solo switch function follows the Pro Tools Operation preference for latched operation. (See the Pro Tools Reference Guide for details.)

#### **Channel Select Switch**

Each channel has a Channel Select switch that performs several functions, depending on the view:

**Home View** The Channel Select switches select the corresponding track (indicated on-screen by a highlighted track name) for record enabling, grouping, and other channel-related commands in Pro Tools.

**Console View** The Channel Select switches select inserts on a particular channel for editing, or select sends between pre- or post-fader.

**Channel View** The Channel Select switches select and edit individual send or insert settings as displayed across the LCD.

#### **Channel Status LEDs**

The Pan/Meter switch to the right of the encoder row lets you choose between left and right sides of a stereo signal.

#### **Channel Meter LEDs**

Each channel includes a five-segment LED meter, scaled at 0, –3, –6, –12, and –42 dBFS.

#### **Channel Data in the LCD**

The LCD displays a variety of channel information, including track, send and insert names, pan position, send levels, or plug-in control information. When you move a fader or rotary encoder, the LCD temporarily shows the value for that control, then returns to the default display.

With the Display Mode switch, you can temporarily display alternate data in the LCD. This lets you confirm track and insert selection when matching levels or comparing settings. For example:

#### To display fader level in the LCD:

- **1** Make sure the Pan switch is lit in the Console section to the left of the encoders. The LCD displays Pan L in the upper left.
- 2 Hold the Display Mode switch. The lower LCD row shows the fader level until you release Display Mode. Rotate an encoder while the Display Mode switch is pressed to display Pan.

#### To display send level in the LCD:

**1** Make sure the Send switch is lit in the Console section.

**2** Hold the Display Mode switch. The lower row of the LCD displays send level for the currently selected send (A–E).

Other view options available from the Display Mode switch are noted throughout this guide, where relevant.

#### **Global Fader Controls**

The following controls affect the assignment and operation of all the faders.

#### Flip Switch

The Flip switch (located to the left of the Navigation keys) invokes Flip mode. Flip mode transfers control assignments from the rotary encoders to the corresponding channel faders, allowing you to use the touch-sensitive faders to edit and automate send and plug-in values.

**Send Flip Mode** When in Home View or Console View, the Flip switch maps send level to the channel faders. The LCD displays the selected send (A–E) for each channel.

**Plug-In Flip Mode** When in Channel View and working with a plug-in insert, the Flip switch moves any plug-in control assignments from the rotary encoders to the faders, letting you use the touch-sensitive faders to edit and automate plug-in control values.

#### **Master Fader Switch**

Pressing the Master Fader switch (to the left of the Navigation keys) arranges all Master Fader tracks in the current session on the right-hand side of the control surface. Pressing this switch a second time returns the control surface to the previous view.

### Console and Channel View Controls for Pan, Sends, and Inserts

The Console and Channel View sections give you control over many on-screen elements in Pro Tools.




Figure 2. Command | 8 Console and Channel View controls

Both Console and Channel views let you view and access pan, sends, and plug-ins for editing, and automation.

#### **Console View Switches**

The different Console Views let you see pan, send, and insert settings of multiple tracks at once in the LCD. Parameters can be adjusted using the switches and rotary encoders.

Pan Sets the rotary encoders to adjust pan. This is the default view that appears when you first launch a Pro Tools session, where the faders control track volume and the rotary encoders control channel pan positions. The LCD shows the track names, and temporarily shows the channel pan positions when the encoder is moved, or volume information when the fader is moved. In this view, pressing a Channel Select switch selects the corresponding track in Pro Tools.

**Send** Sets the rotary encoders to adjust Send level. This view assigns send level controls to the rotary encoders. The LCD shows the names of currently assigned sends across all channel strips for a given send position (Sends A–E in Pro Tools). In this view, pressing a Channel Select switch toggles the selected send on that track between pre- and post-fader operation.

Insert Sets the rotary encoders to inserts or parameters. This view displays the names of currently assigned inserts (hardware inserts or plugins) across all channel strips for a given insert position (Inserts A–E in Pro Tools) in the LCD. If a hardware insert or plug-in is selected in Pro Tools, its name flashes in the LCD. In this view, pressing a Channel Select switch directly under a plug-in name puts Command|8 into Channel View and displays the plug-in controls across all channel strips.

**Insert/Send Position Indicators A–E** Select the send or insert A, B, C, D, or E. These switches determine which of the five available send or insert positions (marked A–E in Pro Tools) are displayed in Console View.


**Default** Resets a fader to its default setting (only applies to fader-mapped parameters).

**Display Mode** Selects display mode options.

**Mon/ø** Toggles Auto Input and Input Only Monitor mode for record enabled tracks.

#### **Channel View Switches**

Channel View focusses on a single track (channel strip) and displays all plug-in, pan, send, or inserts horizontally across the entire LCD.



Channel View Selectors

#### **Channel View Selectors**

**EQ** Identifies channels with equalizer plug-ins assigned to them by illuminating their Channel Select switches. If no EQ plug-ins are present, no Channel Select switches will be lit.

When you press an illuminated Channel Select switch, controls for the first EQ plug-in on that track are assigned to the rotary encoders and displayed in the LCD.

Switched controls (such as Master Bypass or Phase Invert functions) are controlled by the Channel Select switches.

**Dynamics** Identifies channels with dynamics plug-ins (such as compressors or limiters) assigned to them by illuminating their Channel Select switches. If no dynamics plug-ins are present, no Channel Select switches will be lit.

When you press an illuminated Channel Select switch, controls for the first Dynamics plug-in on that track are assigned to the rotary encoders and displayed in the LCD.

Switched controls are controlled with the Channel Select switches below the corresponding LCD display.

**Inserts** When you press the Inserts switch, Command|8 identifies channels with any kind of insert assigned to them (including plug-ins or hardware I/O inserts) by illuminating their Channel Select switches. If no inserts are present, no Channel Select switches will be lit.

When you press an illuminated Channel Select switch, the names of all inserts on that track are displayed in the LCD. To select a plug-in insert for editing, press the corresponding Channel Select switch. (While the names of hardware I/O inserts are displayed, they have no editable parameters, so the Channel Select switches and the rotary encoders have no effect on them.)

Pan/Send/PRE Identifies channels with sends assigned to them by illuminating their Channel Select switches. If no sends are present, no Channel Select switches will be lit.

When you press an illuminated Channel Select switch, the LCD and the first rotary encoder show track pan position for that track. (If the track is a stereo track, you can toggle between left and right pan by pressing the Pan/Meter switch immediately to the right of the encoders.)

Channel Scribble Strips 3–7 show send names and the rotary encoders (3–7) control the levels for all five sends on that track. In this mode, the Channel Select switches on channels 3-7 toggle pre- and post-fader metering for the corresponding send.

Plug-In < Page > Switches Plug-In controls are organized in pages. In a process much like banking of channel faders, when a plug-in has more controls than can fit on the LCD at one time, you can use these switches to page through the plug-in controls.

When a plug-in has multiple pages of controls, the current page (out of the total number) is displayed next to the plug-in Name in the LCD. The Plug-In Page switches will flash to indicate a next or previous page.

Plug-In Master Bypass Switch This switch bypasses either a single plug-in or all plug-ins on a channel, depending on the current view. If the controls for only one plug-in are displayed, only that plug-in will be bypassed. If all the plug-ins on a channel are displayed, all of those plug-ins will be bypassed. If no plug-ins are displayed, the Master Bypass function is unavailable.



👸 Hardware I/O inserts cannot be bypassed in Pro Tools, so the Plug-In Master Bypass switch has no effect on them.

**ESC** (Escape) When flashing, this switch lets you cancel certain operations on the Command|8, such as Channel View selections and many on-screen dialogs in Pro Tools.

### **Transport, Navigation, and Zoom Controls**

These controls mirror the operation of on-screen transport and navigation controls in Pro Tools. In addition, Function keys let you invoke special control surface commands.




Figure 3. Command | 8 transport and navigation controls

### **Transport Controls**

The primary Transport controls match those in the Pro Tools Transport. The additional Record/Playback Mode switches above the Transport controls let you select playback and recording mode.



Command | 8 Transport controls

### **Window Show/Hide Switches**

**Plug-In** Opens or closes the window for the currently selected plug-in

**Mix** Opens, brings forward, or closes the Pro Tools Mix window

**Edit** Opens, brings forward, or closes the Pro Tools Edit window

### **Navigation and Zoom Section**

These multi-purpose keys control the display of Pro Tools tracks on the Command 8 control surface, on-screen zoom functions, and other Pro Tools navigation functions. See "Navigating" on page 32.

#### **Bank, Nudge, and Zoom Switches**

**Bank** When the Bank switch is enabled (lit), the Left and Right arrow keys move the Command|8 tracks across the Pro Tools mixer eight faders at a time.

**Nudge** When the Nudge switch is enabled (lit), the Left and Right arrow keys move the Command 8 tracks across the Pro Tools mixer one track at a time.

**Zoom** When the Zoom switch is enabled (lit), the Left and Right arrow keys zoom the Pro Tools Edit window display horizontally, and the In and Out keys zoom the display vertically.

#### **Navigation and Zoom Keys**

The Bank, Nudge, Zoom, and Arrow keys are used to bank and nudge tracks to the faders, zoom in and out, navigate in text entry fields, and drop Selection In and Out markers on-the-fly.



Bank, Nudge, and Zoom switches

Arrow keys (Left, Right, Up, and Down)

Navigation, Zoom, and Function controls

### **Function/Utility Switches**

**F1 Utility** Enters Utility mode. This is where you set control surface and input preferences, as well as run pre-programmed diagnostic tests.

**F2 MIDI Edit** Lets you edit and name custom MIDI maps to use Command|8 in stand-alone mode only. See Chapter 5, "Using Stand-Alone Mode."


**F3 PRE/MIDI Recall** Enters PRE mode, and accesses controls that let you recall and select presets. For PRE information, see "Controlling PRE" on page 37. For MIDI recall information, see Chapter 5, "Using Stand-Alone Mode."

**F4 Fader Mute** Temporarily disables Command 8 fader movement while working with Pro Tools, allowing you to monitor audio playback without fader noise. To disable fader movement, press F4 while in Pro Tools mode. To restore fader movement, press F4 a second time. The Fader Mute feature has no effect on fader automation or audio levels during playback.

**F5 Focus** Toggles the LCD display between the current plug-in view and the previous Command|8 view (Console or Channel view, or a multi-mono stream list). To return to the original view, press F5 a second time.

### **Monitoring Controls**

Command|8 provides a Control Room section for control over monitor and headphone level. Connect inputs and outputs for monitoring as described below to utilize Command|8 analog monitoring features.



Control Room and Headphone controls

#### To adjust the volume of the Speaker outputs:

■ Adjust the Main Level control.

#### To adjust Headphone volume:

■ Adjust the Headphone level control.

## To toggle input between Main and External Source:

**1** Press the External Source switch to toggle input source. When enabled (lit), Command|8 will monitor the External Source input. When off (unlit), Command|8 monitors the Main input. Command|8 lets you listen to either Main, or Ext Source, but not both simultaneously.

#### To mute the Speaker output:

■ Press Mute in the Control Room section.

#### To monitor in mono:

■ Press the Mono switch.

#### **Headphones**

The Headphone Level adjusts only the output of the Headphones port (located to the right of the headphone Level control).

#### To adjust headphone level:

■ Adjust the Headphone level control.

Headphone output is not affected by status of the monitor Mute switch, but does follow status of the Mono switch.

### **Modifiers Switches**

The Modifiers section is located to the left of the faders, below the Console switches. The Modifier switches provides Windows and Macintosh modifier keys for Pro Tools shortcuts. Use these keys as substitutes for those on your computer keyboard.



Modifiers switches

### **Standalone Switch**

The Standalone switch, located between above and to the right of the Navigation keys, toggles Command Standalone mode on and off. When lit, Command Sis in Standalone mode. When unlit, Command Teturns to its previous operating mode.

For more information, see Chapter 5, "Using Stand-Alone Mode."

### **USB and MIDI Activity LEDs**

The USB and MIDI Activity LEDs indicate USB and MIDI communication status.

The USB LED stays lit when Command 8 is in Pro Tools mode. In other operating modes, the USB LED will darken when controls are moved

The MIDI LED indicates MIDI activity at each of the Command | 8 MIDI ports.

## chapter 4

## **Using Command** 8 with Pro Tools

This chapter explains how to use Command 8 in a Pro Tools session for recording and mixing.

## **Controlling the Transport**

Use the controls in the Transport section to play, stop, record, and cue Pro Tools.



Transport

Command 8 transport, navigation, zoom, and other controls

RTZ (Return to Zero) Sets the playback cursor to the beginning of the session.

**REW (Rewind)** Rewinds through the session from the current cursor position.

FFW (Fast Forward) Fast-forwards through the session from the current cursor position.

**STOP** Stops playback or recording.

**PLAY** Begins playback from the current cursor position.

**REC (Record)** Arms Pro Tools for recording.

## **Record/Playback Mode Switches**

Use the additional Transport switches to enable Loop Playback, Loop Recording, and Quick-Punch modes.



Command 8 also supports TrackPunch recording. See "Punch Recording" on page 35.

**Loop Play** Toggles Loop Playback on and off.

**Loop Rec** Toggles Loop Record mode on and off.

**QuickPunch** Toggles QuickPunch Record mode on and off.

## **Undo and Redo**

To undo the last operation:

Press Undo.

#### To redo the last undone operation:

■ Press Shift/Add+\\(\mathbb{H}\)/Ctl+Undo.

## **Navigating**

Command | 8 lets you select windows, bank other tracks to its faders, and zoom in and out using the controls in the Navigation/Zoom section.

## **Toggling Pro Tools Windows with** the Plug-In, Mix, and Edit Switches

The Plug-In, Mix, and Edit switches in the Windows section open and select their corresponding window in Pro Tools.

**Plug-In** Opens or closes the currently targeted plug-in window. If no plug-in windows are open, the switch opens the window for the first insert on the currently selected track will open.

**A** An open plug-in window is not necessarily the current target. See "Plug-Ins and Inserts" on page 39 for details.

**Mix** Opens or closes the Mix window.

**Edit** Opens or closes the Edit window.

## **Banking Tracks to the Faders**

#### To bank eight tracks at a time to the faders:

- 1 Press Bank. When enabled, its LED is lit.
- 2 Press the Left or Right Arrow keys in the Navigation section to bank to the previous (left) or next (right) eight tracks in the session.

- **3** Repeat as necessary.
  - To show full track names in the LCD, press

Display Mode plus the corresponding channel Select switch. The selected track's full name is displayed across the LCD for as long as you depress Display Mode and the Select switch. Release both to return to the previous view.

#### To scroll tracks across the faders one at a time:

- 1 Press Nudge. When enabled, its LED is lit.
- 2 Press the Left or Right Arrow keys in the Navigation section to nudge one track to the left, or one track to the right.



To manage banking, rearrange tracks in the Mix and Edit windows.

## Zooming

#### To zoom in using Command 8:

- **1** Press Zoom. When enabled, its switch is lit.
- 2 Press the appropriate Arrow key in the Navigation section to zoom in or out: Press the Right arrow key to zoom in; Press the Left arrow key to zoom out.

#### To increase or decrease waveform or MIDI resolution:

- 1 Click with the mouse to place the Play cursor within the track you want to adjust.
- 2 Press Zoom.
- **3** Press the Up arrow key to increase Waveform or MIDI resolution, or press Down to decrease.

#### **Navigating Text Entry Fields**

When editing text and numeric values, the Left and Right Arrow keys let you navigate among editable fields. The Up and Down keys increment or decrement the selected value.

#### **Selection In/Out Points**

In Bank and Nudge modes, the Navigation keys mirror the function of the Up and Down arrow keys on the computer keyboard. These let you mark selection in and out points on the fly, and to move a highlight (selection range) to neighboring tracks.

#### To mark a selection by dropping In and Out points:

- **1** Make sure the Edit cursor is in the track in which you want to select material, and begin playback.
- **2** At the desired in point, press the Down Arrow key.
- **3** At the desired out point, press the Up Arrow key.

#### To move a selection to the previous or next track:

- 1 Make a selection in a track.
- 2 Make sure the Pro Tools is stopped.


- **3** Do one of the following:
  - Press the Up Arrow key to move the selection range to the previous track (above in the Edit window, or to the left in the Mix window). Press the Down Arrow key to move the selection range to the next track (below in the Edit window, or to the right in the Mix window).
  - Hold Shift/Add while pressing the Up or Down Arrow keys to extend the selection to the previous or next tracks.
  - Hold Opt/Alt All while pressing Up or Down to remove a track from an already existing selection.

## **Memory Locations**

Pro Tools Memory Locations (markers) can be created directly from Command |8 during playback or while stopped.

#### To create a Memory Location:

- **1** Cue Pro Tools to the desired location, or begin playback.
- **2** At the desired location, press Enter (located among the switches above and to the left of the Navigation keys).



- **3** Use the mouse to configure the Memory Location dialog onscreen.
- **4** Press Enter again to save, or press Undo to cancel.

#### To open the Memory Locations window:

■ Press the Mem Loc switch. Press Mem Loc again to close the Memory Locations window.

## Recording

Command |8 lets you record audio and MIDI, with support for OuickPunch and TrackPunch recording modes, Loop Recording, and TrackInput monitor switching. Command 8 also directly supports the Digidesign PRE remote controllable microphone preamp.

## **Basic Audio and MIDI Recording**

Basic audio and MIDI recording involves record enabling tracks, arming the transport for recording, and recording.

#### **Record Enabling Tracks**

#### To enable tracks for recording:

- **1** Make sure the Transport is stopped.
- **2** Press the Rec switch located immediately to the right of the channel Select switch row. When Record Enable mode is activated, the lower row of the LCD shows track names, and the Rec switch flashes.
- **3** Press the Channel Select switch for the tracks you want to enable for recording. When a track is armed for recording, its Record Ready LED flashes.

4 Press the Rec switch a second time to exit Record Enable mode and return to the previous Command | 8 view.

- or -

Leave Command 8 in Record Enable mode and use the Transport to begin recording (the Transport remains active in track Record Enable mode).

#### To take tracks out of record enable:

- 1 Press the Rec switch. When the Record Enable function is active, the Record Enable switch flashes.
- 2 Press the Channel Select switch on any track whose Record Ready indicator is flashing to disarm the track for recording. Press the Record Enable switch a second time to exit Record Enable mode and return to the previous Command 8 view.

#### Arming the Transport and Recording

#### To record:

- **1** Make sure you have cued Pro Tools to the appropriate location, or selected the record range in a track. (See the Pro Tools Reference Guide for complete instructions.)
- 2 Record enable tracks as explained in "Record Enabling Tracks" on page 34.
- 3 Press the transport Record switch to arm Pro Tools for recording.
- 4 Configure input monitoring as needed (see "Monitoring while Recording" on page 36).
- **5** Press Play to begin recording. When finished recording, press Stop.

#### To undo a record pass:

Press Undo.

## **Punch Recording**

Command|8 supports QuickPunch and Track-Punch recording. This section explains how to utilize these features from Command|8. For complete information on capabilities and requirements of punch recording, see the *Pro Tools Reference Guide*.

#### **QuickPunch Recording**

#### To record using QuickPunch:

- **1** Press the QuickPunch switch (above the primary Transport switches). When enabled, its LED is lit.
- **2** Record enable tracks (see "Basic Audio and MIDI Recording" on page 34).
- **3** Configure input monitoring as needed (see "Monitoring while Recording" on page 36).
- 4 Begin playback.
- **5** Press the Command 8 master Record switch (in the Transport section) to punch all enabled tracks in and out.

# TrackPunch Recording (Pro Tools|HD System Only)

Command 8 supports TrackPunch as well as TrackInput monitor switching. For more information, see the *Pro Tools Reference Guide*.

#### **Enabling TrackPunch Mode**

#### To enable TrackPunch mode:

■ Hold Ctl/Clutch and press the Transport Record switch repeatedly until the Pro Tools transport displays a "T" in the Record button on screen.

#### **TrackPunch and Record Enabling Tracks**

Before tracks can be punched in and out using TrackPunch, they must first be TrackPunch enabled as well as record enabled. Command|8 features for TrackPunch provide convenient and flexible control of TrackPunch and record enable status.

#### To TrackPunch enable and record enable tracks:

- 1 Make sure TrackPunch mode is enabled.
- **2** Press the Rec switch to enter Record Enable mode.
- **3** Press the channel Select switch for each track you want to TrackPunch enable. A single press TrackPunch enables and record enables the track as explained previously.
- **4** Press the channel Select switch again. This takes the track out of record enable but leaves it TrackPunch enabled. Onscreen the track Record button is lit blue
- Hold Opt/Alt All+Shift/Add to TrackPunch enable all selected tracks.

# To TrackPunch enable tracks without record enabling them:

- **1** Make sure TrackPunch mode is enabled and the Transport is stopped.
- **2** Press Ctl/Clutch+Channel Select to Track-Punch enable that track.
- **3** To TrackPunch enable additional tracks, press Ctl/Clutch+Channel Select for each desired track. Onscreen, the track record buttons flash blue and red indicating they are both Track-Punch enabled and record enabled.

#### To take tracks out of TrackPunch and record enable:

- 1 Press Ctl/Clutch+Select (Windows) or 第/Ctl+Select (Macintosh) on each track. One press immediately places the track in Record Safe mode.
- 2 Repeat to take the track out of Record Safe and leave it not TrackPunch enabled or record enabled. Use the standard Pro Tools modifiers to Apply to All (Opt/Alt All) or Apply to Selected (Shift+Opt/Alt All). If some tracks are already TrackPunch enabled, applying to all will first take all tracks out of TrackPunch enable. Repeat step 3 and all tracks will TrackPunch enable.

#### To take a track out of record enable but leave it TrackPunch enabled:

- 1 Press the Rec switch.
- 2 Press the corresponding Channel Select switch.

#### **Punching In and Out using TrackPunch**

#### To punch on individual tracks using TrackPunch:

- 1 Configure Pro Tools for TrackPunch recording as explained in the Pro Tools Reference Guide.
- 2 TrackPunch and record enable tracks as explained previously.
- **3** Press the Transport Record switch to arm Pro Tools for recording.
- 4 Begin playback.
- **5** Use the channel Select switches to punch in and out on individual tracks.

#### To punch multiple tracks simultaneously using TrackPunch:

- 1 Enable TrackPunch mode.
- 2 Press the Rec switch, then press the channel Select switch to TrackPunch enable and record enable tracks.
- 3 Begin playback.
- 4 Press the Transport Record switch to punch all TrackPunch and record enabled tracks in and out simultaneously.

## **Monitoring while Recording**

Command | 8 lets you toggle Pro Tools record monitor modes, as well as use TrackInput monitor switching.

### **Toggling the Record Monitor Mode**

#### To toggle record enabled tracks between Auto Input and Input Only Monitoring modes:

- **1** Make sure the transport is stopped.
- 2 Press Mon/ø to toggle Monitor mode. The LCD displays Auto when Auto Input mode is enabled, and Input when Input Only mode is enabled.

## **TrackInput Monitor Switching**

(Pro Tools HD Systems Only)

#### To use TrackInput monitoring:

1 Press Opt/Alt All+Mon/ø (Windows) or Ctl/Clutch+Mon/ø (Macintosh). The upper left of the LCD displays Select Input Monitor, and the Mon/ø switch flashes.

**2** Press the channel Select switches to toggle tracks between Input monitoring and disk monitoring. When Input is enabled, the LCD above the selected track displays Input. When monitoring from disk, the LCD displays AutoIn.

#### To query Input status of all tracks:

- **1** Make sure no tracks are record enabled.
- 2 Press Mon/ø to temporarily display the input status (Input, or AutoIn) of all displayed tracks.
- 3 To query other tracks, bank those tracks to the faders and repeat.

## **Loop Recording**

Command | 8 supports Loop Record mode for audio and MIDL

#### To enable Loop Record mode:

■ Press the Loop Rec switch in the Transport section. When enabled, the Loop Rec switch LED is lit. Press the Loop Rec switch again to take Pro Tools out of Loop Record mode.

## **MIDI Recording**

MIDI tracks can be record enabled using the same techniques as with audio tracks. See "Basic Audio and MIDI Recording" on page 34.



**A** On Macintosh systems using the Command 8 MIDI ports as a MIDI interface, make sure no MIDI tracks are assigned to "Port 1." This port is reserved for Command 8 control surface communication. *Use Port 2, or Port 3, depending on which* port is connected to your MIDI device as explained in "Configuring Command|8 MIDI Interface Connections" on page 15.

## **Controlling PRE**

#### (Digidesign PRE Microphone Pre-Amp)

If you use one or more PRE units with your Pro Tools system, you can use Command 8 rotary encoders to adjust channel gain.

## **MIDI Connections for PRE with** Commandi8

PRE can be connected to Command |8 MIDI In and MIDI Out 1 ports, or to an available pair of ports on another MIDI interface being used with Pro Tools. PRE must be connected and enabled within Pro Tools before Command 8 can control it (see the *PRE Guide* for more information).

#### **Adjusting PRE Gain**

#### To adjust PRE gain from Command 8:

- 1 Make sure PRE is connected, and that it has been enabled in the Peripherals dialog (see the PRE Guide for details).
- **2** Make sure you have assigned PRE inputs to one or more tracks. (You cannot assign PRE inputs to tracks from Command 8; you must use the mouse and onscreen controls in Pro Tools.)

3 Press F3 PRE/MIDI Recall. The LCD displays PRE unit number, channel number, and gain value in the LCD above each audio track. Because multiple PREs can be in use, unit and channel number are indicated as follows.

PRE unit number (top row) per channel (lower row) as displayed in the LCD

1/1 10	1/2 21	1/3 54	cont.
(ch 1)	(ch2)	(ch3)	(chs4-8)

- The first two numbers per channel indicate unit and channel number. Above, "1/1" indicates PRE unit #1, channel 1; "1/2" indicates unit #1, channel 2). If using two units, their channels (when banked) would be listed as "2/1", "2/2" and so on.
- The two digit gain value for that unit and channel (PRE gain ranges from 0-69).
- 4 Rotate the encoder below the desired unit and channel shown to adjust PRE gain on that channel.
- **5** Bank left or right to bank other PRE tracks to the channel strips.

## **Sends**

Command | 8 lets you adjust Pro Tools send level, pan, pre/post fader tap, and send mute. (You cannot assign or remove sends from Command|8; use Pro Tools onscreen controls and the mouse instead.)


Sends can displayed and accessed in either Console or Channel View modes.



The F5 Focus switch toggles between the current and previous Console or Channel view. See "Function/Utility Switches" on page 28.

#### To view and adjust send levels for all currently banked tracks (Console View):

- 1 Press the Send switch to the left of the rotary encoders to enter Send view.
- 2 Select a send (A–E) by pressing the corresponding switch from among the Send A-E switches at the far left of the control surface. The LCD displays the status of the selected send (A–E) of each currently banked track (whether assigned to a bus, output, or none).



#### To view and adjust sends on a single track (Channel View):

- 1 Press the Pan/Send switch in the Channel View switch section.
- 2 Press a channel Select switch. The corresponding track Name appears in the LCDs upper row, Pan in the first channel of the lower row, and the five sends for the track are listed across channels 3-7. This means that Send A for the selected track is shown in channel 3, Send B in channel 4, and so on. The send assignment is shown above each channel (bus 1-2, output 3-4, and similar).
- **3** Use the rotary encoders to adjust send levels.
- To check the selected track name, press and hold Display Mode. Release to return to the previous view.

#### To lock the LCD to show send level:

1 Press ♯/Ctl+Display Mode. The LCD will continue to display send level even if the channel fader is adjusted. Press the Pan switch to return to default view.



Inactive sends are indicated with "@" preceding their display.

#### To toggle a send between pre- and post-fader:

■ With the desired send displayed, press the Channel Select switch. A lit (yellow) Select switch indicates pre-fader; unlit indicates postfader.

#### **Muting Sends**

#### To mute a send:

■ Press \(\mathbb{H}/\text{CTL+Select on the channel containing the send you want to mute.

The switch LEDs light red to indicate bypassed, green to indicate in (not bypassed), and alternating red and green to indicate mixed states of muted and un-muted sends.

## **Send Flip Mode**

Send Flip mode lets you flip control of send level to the touch-sensitive faders. Send Mute is mapped to the channel mute switch, the encoders control send pan (if a stereo send), and the channel Select switches toggle pre/post fader status.

#### To enter Send Flip mode:

- 1 Press Send, then select a send A-E as described above.
- 2 Press the Flip switch (to the left of the Navigation keys).

- **3** Adjust send level using the channel faders, and adjust send pan using the rotary encoders.
- To show send level in the LCDs, press Display Mode while in Flip mode. Release to return to the previous view.

#### To mute a send in Send Flip mode:

Press the channel Mute switch.

#### To toggle pre/post fader status in Send Flip mode:

Press the channel Select switch.

For stereo tracks with stereo sends, pressing the Pan/Meter switch immediately to the right of the encoders toggles between left and right signals. Both the LCD and the LEDs above the Pan/Meter switch indicate whether the left or right pan position is displayed.

## **Plug-Ins and Inserts**

Command | 8 lets you quickly access and adjust plug-ins using the Channel View switches, rotary encoders, and other controls. Command | 8 supports Pro Tools target windows for control surface focus (see "Target Plug-Ins and Plug-In Windows" on page 40).



You cannot edit plug-ins or inserts on Command|8 when used in combination with Digi 002. Use the Digi 002 control surface, or Pro Tools onscreen controls.

The EQ and Dynamics switches provide direct access to EQ and Dynamics category plug-ins, respectively (see "EQ and Dynamics" on page 42).

Flip mode maps plug-in controls to the faders for finer control when editing or automating. Hardware inserts can be taken in and out of bypass (see "Plug-In Flip Mode" on page 42).



The F5 Focus switch toggles between the current and previous Console or Channel view. See "Function/Utility Switches" on page 28.

### **Target Plug-Ins and Plug-In Windows**

Command|8 can select, target, and open the window of a plug-in. Whenever you open a plug-in using Command|8, that plug-in becomes the control surface target window and is the focus of Command|8 faders, switches, and rotary encoders (as available).

Pro Tools 6.4 and higher supports multiple target windows. While this adds flexibility for simultaneously viewing and editing parameters from a control surface, it requires that you make sure you verify the target window whenever multiple plug-in windows are open, and whenever you first open a session.

For example, support for multiple targets means that an open (onscreen) plug-in window may not necessarily be the current control surface target. In addition, a plug-in window does not necessarily have to be open to be the target. This can occur when opening sessions that were saved with windows and targets in certain states of focus.

Selecting and opening plug-ins from Command |8 Console and Channel view controls automatically target the selected plug-in.

For information on verifying the target, see "Adjusting Plug-Ins" on page 41.

## **Opening Plug-Ins**

Plug-ins can selected in Console or Channel View modes. Selecting a plug-in for editing makes it the Command 8 target.


Console view lets you view, select, and bypass from among the current plug-in assignments of multiple tracks. Channel view lets you navigate among all plug-ins and inserts on a single track.

# To view and select plug-ins of all currently banked tracks (Console view):

- **1** Press the Insert switch to the left of the rotary encoders. The upper row of the LCD displays the current insert A–E, and indicated Console view by displaying "All Channels." The lower row shows the name of any plug-ins in that insert position (A–E) for each currently banked track.
- **2** To select a different insert (A–E), press the corresponding A–E switch.
- **3** When the name of the desired plug-in is displayed, press the corresponding channel Select switch (in the channel below the displayed insert name). The plug-in window opens onscreen, and Command 8 displays the first page of plug-in parameters across the LCD.

# To view all inserts on a single track (Channel View):

**1** Press the Insert switch in the Channel View row. Track names are shown in the lower row of the LCD. The name of the most recently edited track flashes.



2 Press the channel Select switch for the track containing the plug-in you want to edit. The selected track name appears in the upper row of the LCD. The lower row shows the name of any plug-ins assigned in that track above channels 1–5 (channel 1 shows insert A, channel 2 shows insert B, and so on). Inserts with no plug-in or hardware insert assignments are indicated with a straight horizontal line.

To check the selected track name, press and hold Display Mode. Release to return to the previous view.

**3** Press the corresponding channel Select switch to select and open a plug-in.

inactive inserts are indicated with "@" preceding their name.

#### **Closing Plug-In Windows**

#### To close all plug-in windows:

■ Press Opt/Alt All+Plug-In (in the Windows section).

### **Adjusting Plug-Ins**

A plug-in must be selected and targeted before you can adjust its parameters from Command|8.

# To target a plug-in for editing from Command | 8, do one of the following:

■ Select and open the plug-in using Command 8 Channel or Console views (see "Opening Plug-Ins" on page 40.

# To target a plug-in window already open onscreen (making it the Command 8 focus);

• Click in the header area of an open plug-in window (the blank gray area next to the standard plug-in controls at the top of the window).

Once an insert is targeted for editing, you can adjust the displayed parameters, bank to other plug-in pages to access other controls, and use Flip mode to map plug-in parameters to the faders.

#### To adjust a plug-in parameter:

- **1** Select an insert for editing as described in "Opening Plug-Ins" on page 40.
- **2** Use the rotary encoder under each displayed parameter that maps to a variable control (sliders, knobs, and similar). Use the appropriate channel Select switch to toggle on/off switches.

## **Bypassing Plug-Ins**

Command 8 provides the following ways to bypass inserts.

#### To bypass the currently focussed insert:

- **1** Select an insert for editing and display its controls in the LCD.
- 2 Press Master Bypass.

#### To bypass a plug-in from Console or Channel views:

- **1** Use the Console or Channel view switches to display all inserts (A–E) on all currently banked tracks (Console view), or to display all inserts on a single track (Channel view). See "Opening Plug-Ins" on page 40.
- 2 Press \( \mathbb{H}\)/Ctl+Select on the channel corresponding to the insert you want to bypass. Press again to disengage bypass.

The switch LEDs light red to indicate bypassed, green to indicate in (not bypassed), and alternating red and green to indicate mixed states of bypassed and un-bypassed plug-ins.

#### **Navigating Plug-In Pages**

#### To show other plug-in control pages:

■ Use the < Page > switches (in the Channel View row below the LCD) to bank to the previous or next page of plug-in controls.

#### **Multi-Mono Plug-ins**

When working with a multi-mono plug-in, you can toggle the view between the left and right sides.

#### To select left or right sides of a multi-mono plug-in:

1 Select a track and display its inserts in Channel view as described previously.

– or –

Select a multi-mono insert and press Display+F5 to display the available signals (left, center, or right).

The LCD displays the track and plug-in name, with each mono signal listed across an appropriate number of channels.

- 2 Press a channel Select switch to select the corresponding left, center, or right signals of the plug-in.
- **3** Press the lit Select switch to the right to bypass the corresponding signal (L, C, or R).

## **EQ** and **Dynamics**

The EQ and Dynamics switches let you quickly access EQ and Dynamics plug-ins in your session. (Dynamics plug-ins include compressors, limiters, expanders, and gates.)

#### To use EQ to access an EQ plug-in:

1 Press EQ in the Channel View section. Any currently banked tracks containing EQ plug-ins are indicated by their Select switch flashing.

- 2 Press a flashing Select switch to open the first EQ on that track, or the most recently edited EQ plug-in if more than one.
- 3 To cycle through multiple EQ plug-ins on the track, hold the EQ switch and press the Channel Select switch again.
- 4 To move to a different track, press a channel Select switch.

## Plug-In Flip Mode

Plug-in Flip mode maps plug-in parameters to the faders, for greater control and touch-sensitive automation writing.

#### To use plug-in Flip mode:

- 1 Focus Command 8 on an active plug-in to display its parameters across the LCD. (See "Opening Plug-Ins" on page 40 for instructions.)
- **2** Press the Flip switch. The parameters that were displayed for the rotary encoders are mapped to the faders.
- 3 To exit Flip mode, press the Flip switch a second time.
- To temporarily show the full name of a plug-in parameter in the LCD, press Display Mode+the corresponding channel Select switch. Release to return to the previous view.

## **Software Synths and Rewire Applications**

Command 8 automatically supports any software synthesizers running as TDM or RTAS plug-ins in Pro Tools (see "Plug-Ins and Inserts" on page 39).

Stand-alone software synths, samplers, effects, and Rewire-compatible applications (such as Reason, Live, and similar) can also be controlled by Command|8, letting you switch back and forth between environments while maintaining tactile control of session functions.

Doing so utilizes Command | 8 Stand-alone mode, in which faders, encoders, and switches can be programmed to control virtually any software or hardware device parameter that supports MIDI CC messages. Eight user presets can be stored and recalled in onboard memory, with support for SysEx dump and recall. For more information, see Chapter 5, "Using Stand-Alone Mode."

## chapter 5

## **Using Stand-Alone Mode**

This chapter explains how to configure and operate Command 8 in stand-alone mode.

# Overview of Stand-Alone Mode

In Stand-alone mode, Command 8 can be used with other (non-Pro Tools) software and hardware MIDI devices.

Each of the Command 8 faders, encoders, and switches in the fader strips (four per channel strip or 32 total) can be custom programmed to control any compatible parameter. For an overview of programmable controls and their default assignments, see "Mapping" on page 47.

As many as eight preset MIDI maps can be saved and recalled. Each preset can save custom maps of two pages of supported controls. Presets let you store maps for as many as eight unique devices.

Once stand-alone mode has been configured and your presets stored, you can be working with Command|8 in Pro Tools, then switch to stand-alone mode to refocus to a stand-alone software synth, or a ReWire-compatible application such as Reason or Live. (Because these are separate applications, and not plug-ins within the Pro Tools MIDI environment, stand-alone mode is required to control their faders, encoders, and switches.) Check to see if your software applications support USB MIDI communication and the Command|8 Personality protocol, or if 5-pin DIN MIDI connections are required to a compatible MIDI interface.

## **MIDI Compatibility**

Command 8 supports any device that supports MIDI continuous controller (CC) and note data. SysEx dumping and loading is also supported in stand-alone mode. Drivers are provided that let Command 8 be used as a MIDI control surface on supported Windows or Macintosh computer with virtually any compatible software.

## **Stand-Alone Mode QuickStart**

This section lists the basic steps required use Command 8 in stand-alone mode. Detailed instructions for each step can be found later in this chapter (as indicated below).


#### Configuring Stand-alone mode involves the following tasks:

- 1 Entering Stand-alone mode (see "Selecting Stand-Alone Mode" on page 46.
- 2 Navigating and selecting presets (see "Navigating Presets and Pages" on page 47.
- 3 Programming Command 8 faders, encoders, and switches for the device you are controlling, if necessary, with custom naming options (see "Editing MIDI Maps" on page 49.
- 4 Naming, saving, and recalling presets (see "Presets to Save and Recall Maps" on page 51).

## **Selecting Stand-Alone Mode**

#### To place Command 8 in Stand-alone mode:

1 Press the Standalone switch, next to the Status LEDs.



Standalone switch

When in stand-alone mode, the switch LED lights.

The last saved (or default) MIDI map is recalled and its status is displayed in the LCD, similar to the following:

#### Example display of a preset in stand-alone mode

Fader1	Fader2	(3–6)	Fader7	Fader8
0	0		0	0

- The upper LCD row displays the fader name (Fader1, Fader2).
- The lower row shows the current value (level).

Move any fader to see its position displayed in the lower row of the LCD.



Editing a preset does not automatically save the changes stored locally by Command 8. As you progress through the following pages and program your presets, be sure to use the Command | 8 Save commands frequently to save your edits to flash memory. You can also save preset configurations with SysEx. See "Presets to Save and Recall Maps" on page 51.

## **Navigating Presets and Pages**

In stand-alone mode, the F3 PRE/MIDI Recall switch enters a display mode that lets you navigate and select among the eight available Command | 8 presets.

#### To navigate to a different MIDI Map preset (1-8):

1 In Standalone mode, press F3 PRE/MIDI Recall. The LCD shows the number and name of the current preset above channels 1 and 2, respectively. Cancel, Recall, and Save commands are provided in channels 6-8, similar to the following.

F3 PRE/MIDI Recall display

Preset Number	Name	Cancel	Recall	Save
4				Edited
ch 1	ch 2	ch 6	ch 7	ch 8

- 2 Rotate the channel 1 encoder to scroll the Preset# through the eight available presets. If any custom names have been saved for presets, their names will also appear in the channel 2 LCD.
- 3 To cancel MIDI Recall and return to the previously displayed preset, press the channel 6 Select switch.
- 4 To select the currently displayed preset, select Recall by pressing the channel 7 Select switch. The LCD prompts you to confirm that you want to recall and load the selected preset from internal flash memory.
- **5** To confirm, press the channel 7 Select switch (OK). The selected preset is loaded and displayed across the LCD.

To begin programming controls, see "Programming Controls" on page 49. To begin by naming and saving your presets, see "Presets to Save and Recall Maps" on page 51.

#### **About Preset Pages**

Each Command | 8 preset provides two pages, or banks, of programmable controls. In other words, the progammable faders, encoders, and switches can each be given two unique assignments per preset (one assignment, per control, per page).

#### To bank to the other page of a preset:

■ In Standalone mode, press the Bank switch.

By default, both pages of each preset share identical values for programmable faders, encoders, and switches within the same preset. This provides an efficient and practical starting point for complex custom mapping, as pages automatically share the most common and needed assignments (such as faders always controlling volume).

By default, page 1 uses MIDI channels 1-8, and page 2 uses MIDI channels 9-16. You can customize MIDI channel assignment as needed (see "Programming Controls" on page 49).

## **Mapping**

Command 8 faders, encoders, and 24 of its switches can be programmed, or mapped, to CC values required to control other devices. As many as eight presets can store unique, custom MIDI maps, each with two pages (or banks) of programmable switch functionality.

In addition, the primary Transport switches, as well as the eight Channel Mode switches, are factory-assigned in all presets (and can not be customized).

# Mapping is a simple process that involves the following tasks:


- Edit MIDI Maps. Touch to select faders, encoders, and switches, then assign custom MIDI Continuos Controller or switch values to match the target device, as needed. See "Editing MIDI Maps" on page 49.
  - and -
- Use Presets to Save and Recall Maps. Save and recall up to eight custom MIDI maps in Command|8 Presets. See "Presets to Save and Recall Maps" on page 51 for more information.

#### **Controls in Stand-Alone Mode**

**Faders** Each fader can be mapped to any MIDI Continuous Controller (CC). Default is Volume (#07). Start and end MIDI values, as well as custom names, can be specified for each fader.

**Encoders** Each encoder can be mapped to any CC. Default is Pan (#10). Start and end MIDI values, as well as custom names, can be specified for each encoder.

**Switches** In stand-alone mode, 32 of the Command 8 switches are available in both pages of each preset.



Programmable switches in stand-alone mode

The channel Mute and Solo switches are premapped to CC 14 (mute) and CC 15 (solo); Channel Select switches are not premapped.

The Channel View selectors (EQ, Dyn, Insert, Pan/Send, < > Plug-In Page, Master Bypass, and Esc) are dedicated (pre-programmed) to CC 121–127 as follows (they retain these assignments even when switching pages or presets, and can not be changed.

#### Channel View switch CC assignments

Switch	CC assignment
EQ	121
Dynamics	122
Insert	123
Pan/Send	124
< Page	125
Page >	127
Master Bypass	toggle Latch/Momen
Esc	Name (edit)

**Transport Switches** The Transport switches are permanently mapped to standard MMC (MIDI Machine Control) messages. (The RTZ switch does not support MMC.)

#### The following controls are not programmable:

- Encoder mode selectors
- Display Mode
- Modifiers
- Master faders
- Flip
- Bank
- Nudge
- Arrows
- F1-F5
- Standalone
- · Control Room switches.

## **Editing MIDI Maps**

This section provides instructions for programming (mapping) Command 8 faders, encoders, and switches.



Custom mapping can be saved as presets, and presets can be created, named, and saved before doing any mapping. See "Presets to Save and Recall Maps" on page 51.

#### To enter MIDI Edit mode:

- **1** Make sure Command|8 is in stand-alone mode.
- **2** Press F3 PRE MIDI Recall and select a preset to edit. (See "Selecting Presets" on page 51.)
- **3** Press F2/MIDI Edit. The F2 switch LED flashes, and the LCD display shows parameters similar to the following tables (which show default assignments for Fader 1 as an example):

F2 MIDI Edit display, channels 1-4

Select	control	Chan	СС
Fader1		1	7
ch 1	ch 2	ch 3	ch 4

- The currently selected control (usually Fader1 or the last edited) is shown in the lower row of channel 1.
- Channel 3 shows the current MIDI Channel in the lower row.
- Channel 4 shows the current CC value in the lower row.

F2 MIDI Edit display, channels 5-8

Lo Val	Hi Val	Mode	Name
0	127	Single	Fader1
ch 5	ch 6	ch 7	ch 8

- The upper row shows the available parameter names for (MIDI) Lo and Hi Value, Mode, and Name.
- The lower row shows the current value (1–127) for Lo and Hi Value, the current Mode (single or double), and the current control name (for example, Fader1).
- 4 To select a different control, touch a fader, adjust an encoder, or press one of the programmable switches. To select an encoder, rotate Encoder #1 to scroll through the list of a available encoders. The selected control name appears across controls as needed (see "Programming Controls" on page 49).
- **5** Press F2/MIDI Edit to exit MIDI Edit mode. If you have changed any settings, you will be prompted to save before exiting. Follow the instructions onscreen. The F2 switch LED should stop flashing.

## **Programming Controls**

Programming controls involves the following basic steps:

- Selecting (focusing) the control
- Configuring its MIDI channel, CC#, and other parameters
- Naming and saving the edited preset

#### To select a control to program:

**1** Select a preset and enter MIDI Edit mode (see "Selecting Presets" on page 51 for instructions).

- 2 Select the fader, encoder, or switch you want to program by doing any of the following:
  - To select a fader, move the fader. (See "Programming Faders" on page 50 for fader details.)
  - To select an encoder, rotate the channel 1 encoder and scroll through the list of programmable switches until the Encdr (Encoder) names appear, then scroll to the desired encoder 1–8. (See "Programming Encoders" on page 50 for encoder details.)
  - To select a switch, press any progammable switch (see "Programming Switches" on page 51 for switch details).
- **3** Make sure the name of the fader, encoder, or switch you want to program is displayed in the lower row of the LCD above channel 1.

#### To set the MIDI channel:

■ Rotate the channel 3 encoder for Chan until the desired channel is displayed (default is channel 1).

#### To set the CC#:

■ Rotate the channel 4 encoder for CC# until the desired value is displayed.

#### To set a Lo or Hi MIDI Value:

- 1 Rotate the channel 5 encoder to set a MIDI Lo Value (0-127).
- 2 Rotate the channel 6 encoder to set a MIDI Hi Value (0-127).

#### To program a switch for momentary or latching:

- **1** Select the switch to edit.
- **2** Rotate the channel 7 encoder (Mode) to choose Latch or Momen (momentary).

#### To set a fader or encoder for single or double precision:

- 1 Select the fader or encoder.
- 2 Rotate the channel 7 encoder (Mode) to choose Single or Double.

#### To name a control:

- **1** Select the MIDI preset and control you want to name.
- 2 Rotate the channel 8 encoder (Name). This displays the Name parameters in the LCD.
- 3 Rotate encoder 2 to scroll and select lowercase, upper-case, or numerics for the first character of the custom name.
- 4 When the desired character is displayed, rotate encoder 1 to move to the next character (its cursor flashes). Repeat for the remaining characters to enter your custom name.

### **Programming Faders**

Each fader can be mapped to any MIDI continuous controller. Each fader defaults to a unique MIDI CC number corresponding to Volume (#07). Assignment can be changed to any other CC number. Start and End MIDI values, as well as custom parameter names, can also be specified for each control.

## **Programming Encoders**

Each encoder can be mapped to any MIDI continuous controller, and defaults to Volume (#07). Encoders support velocity sensitive editing, and can be custom named.

#### **Programming Switches**

The 24 switches in the fader section that can be custom mapped in Standalone mode include the channel Select, Solo, and Mute switches.

The eight Channel View switches across the top of the channel strips are also available, but are permanently configured to CC 121-127 (left-toright). In addition, the Transport switches are permanently configured to MMC (MIDI Machine Control) transport command assignments.

## Presets to Save and Recall **Maps**

Presets are snapshots of MIDI mapping assignments that can be saved and recalled.

You can store up to eight presets to save custom mapping and MIDI channel assignment for a variety of devices, with custom names. Presets can be recalled at any time to instantly switch to a different device mapping.

## **Selecting Presets**

#### To select a Comand 8 stand-alone mode preset:

- 1 In stand-alone mode, press F3 PRE MIDI Recall.
- **2** Rotate the channel 1 encoder to scroll through available presets, and stop when the desired preset name is displayed.
- 3 To select the displayed preset, press the channel 7 Select switch (Recall).
- 4 Press the channel 7 Select switch (Okay) again to confirm you want to load the preset from flash memory. (To cancel, press channel 6 Select.) The select preset is loaded and displayed in Command 8.

**5** When finished selecting a preset, press the channel 7 encoder (Okay), or press the channel 6 encoder (Cancel) if you need to cancel the naming.



**A** *Edited presets must be manually saved to* flash memory to be able to be recalled later (Command|8 warns you to save any changed presets if you leave Stand-alone mode, but it does not automatically save presets as you edit them). See "Saving Command | 8 Presets" on page 51.

## **Saving Command 8 Presets**

Command | 8 presets can be saved to flash memory to save custom mapping of programmable controls, custom names, and all other parameters associated with all eight presets.

Command|8 presets can also be stored (dumped) to SysEx through USB or 5-pin DIN connections.

#### To save the current preset:

- 1 If not already opened and displayed, press F3 PRE MIDI Recall to select the desired preset.
- 2 Press the channel 8 Select switch (Save).
- 3 Press the channel 7 Select switch (OK) to save the preset to onboard Flash memory. (To save presets through MIDI, see "Loading and Saving Presets with SysEx" on page 52.)
- 4 Command 8 asks you to confirm that you want to save the currently displayed preset to flash memory (replacing and updating any previously stored preset in flash memory).
- **5** To confirm and save, press the channel 7 Select switch (Okay). To cancel without saving, press the channel 6 Select switch (Cancel).

## **Loading and Saving Presets with SysEx**

Command|8 supports SysEx to store and recall presets into and out of Pro Tools or any compatible device. SysEx provides a standard and reliable way to quickly archive, and later retrieve entire sets of Command|8 presets.

#### To save the current presets to SysEx:

- 1 If not already opened and displayed, press F3 PRE MIDI Recall to select the desired preset.
- 2 If recording SysEx into Pro Tools MIDI track, do the following:
  - · Enable Wait for Note
  - · Create a new MIDI track (if necessary) and configure input and output as described in the Pro Tools Reference Guide.
  - Configure the MIDI Input Filter dialog to enable SysEx recording.
  - Record enable the MIDI track, and arm the Pro Tools Transport for recording (be sure you enabled Wait for Note so that recording will not begin until the SysEx transfer starts).
- **3** Press the channel 8 Select switch (Save).
- 4 Press the channel 2 Select switch to cycle through available destinations
  - To save to a SysEx destination connected through USB (such as Pro Tools), choose MIDI/USB.
  - To save to a SysEx destination connect through 5-pin DIN MIDI connections, choose MIDI/DIN.
- **5** When the desired destination is chosen, press the channel 7 Select switch (OK).

- 6 When Command 8 prompts you to save the currently displayed preset to flash memory, do one of the following:
  - To confirm and save, press the channel 7 Select switch (Okay). This replaces the preset previously stored in flash memory.
  - or –
  - To cancel without saving, press the channel 6 Select switch (Cancel).

If you OK the SysEx dump, the LCD displays a status message until the transfer is completed, after which it returns to the previous preset view.

#### To load (recall) presets from SysEx:

- **1** Make sure the device from which you will be loading SysEx data is connected properly to Command 8 (either through a USB MIDI or a 5pin DIN MIDI connection).
- 2 If loading from a Pro Tools track, cue Pro Tools to the appropriate location before the SysEx data.
- 3 Press F3 PRE MIDI Recall, Scroll to the Command|8 preset where you want to load (overwrite) the incoming preset being recalled.
- 4 Press the channel 7 Select switch (Recall).
- 5 Press the channel 2 Select switch to choose either USB MIDI or MIDI/DIN to recall from. If loading from a Pro Tools MIDI track, choose USB MIDI.
- **6** Press the channel 7 Select switch (Okay). Command | 8 waits for SysEx data to begin arriving.
- 7 Begin the SysEx source device (if using Pro Tools, begin playback). Command 8 displays a status message while loading.

## **Naming Presets**

You can save custom names for presets, making it easier to manage multiple presets for different devices.

#### To name a Command|8 preset:

- 1 Press the Standalone switch (located next to the USB and MIDI status LEDs), to enter standalone mode.
- 2 Press F3 PRE MIDI Recall.
- 3 Navigate to the preset you want to name by rotating the channel 1 encoder until its number (or previous name, if any) is displayed.
- 4 Press the channel 2 Select switch to enter Preset Name mode. The LCD displays a flashing cursor in the lower row of channel 1.
- 5 To name your preset, choose letters by rotating the channel 2 encoder (Char) until the desired letter or number is shown. Scroll through the entire range of choices to access upper case letters.
- 6 Rotate the channel 1 encoder (Cursor) clockwise to advance the flashing cursor to the next (or any) character space available for the preset name. Rotate the channel 2 encoder to choose a character, and repeat for additional characters.
- **7** When you have entered the desired name, press the channel 7 Select switch (Okay). Or, to cancel, press channel 6 Select (Cancel).

## **Naming Controller Assignments**

You can give each programmable control its own custom name. Some people get by with the default controls and their own memory. Others will appreciate the ability to give parameters names that indicate the control to which they are mapped, such as whether a fader or encoder is mapped to a frequency slider in an EQ or a filter resonance control in a soft synth.

#### To save names for programmed controls:

- 1 Select the preset containing the control you want to name.
- **2** Select the control for MIDI editing.
- 3 Rotate the channel 8 encoder (Name). The LCD now displays Cursor, Char, Cancel, and Okay in the upper row, with a flashing cursor in the lower row above channel 1.
- 4 To enter a name, rotate the channel 2 encoder (Char) until the desired letter or number is displayed.
- 5 Rotate the channel 1 encoder (Cursor) to move the cursor to the next character space, and repeat until you have entered the desired name.

## appendix a

# **Utility Functions**

Command 8 Utility functions include the following:

- Software and firmware version display
- Fader calibration
- Tests for faders, encoders, LEDs, switches, and the LCD

## **Accessing Utility Mode**

#### To access Command 8 Utility mode:

- 1 Press F1 Utility. The LCD displays the available Utility functions across the upper row. The corresponding channel Select switch select each option.
- 2 Press a channel Select switch to choose a Utility function.
- 3 To cancel a Utility function or test at any time, press Select on channel 8 (the LCD displays ESC above channel 8), or press Utility again.

## **Viewing Command|8 Version Data**

This Utility function lets you check the current firmware version and other statistics useful when upgrading, or when contacting technical support.

#### To display Command | 8 version data:

- **1** Access Utility mode.
- 2 Select Vers by pressing the corresponding channel Select switch. The LCD shows version information about various components of Command|8.
- **3** To exit, press channel eight Select (below the LCD display ESC).

### **Fader Tests**

Command|8 provides tests for fader and group performance.

Use this routine to return the motorized, touchsensitive faders to their factory calibration setting.

#### **Touch Circuit Test**

#### To reset the faders:

- **1** Press F1 Utility, to enter Utility mode.
- **2** Select Fadcal by pressing the channel 1 Select switch. Do not touch the faders, as the fader routine begins immediately and moves the faders through their range of travel. The lower row of the LCD shows fader resolution while the test is in process.
- **3** Faders park at the bottom of the fader paths when recalibration is complete.
- 4 Press the channel 8 Select switch (Esc) to exit.

#### **Fader Tests**

These functions test fader performance and fader group resolution. You can use these routines to troubleshoot the mechanical elements of the Command 8 faders.

#### To test fader resolution:

- **1** Press F1 Utility, if necessary, to enter Utility mode.
- **2** Select Fader by pressing the channel 2 Select switch. The LCD displays the available fader Utility functions.
- **3** Select FadTst by pressing the channel 2 Select switch. Do not touch the faders.

**4** Press the channel 8 Select switch to stop the test.

#### To test fader group resolution:

- **1** Press F1 Utility, if necessary, to enter Utility mode
- **2** Select Fader by pressing the channel 2 Select switch.
- **3** Select Group by pressing the channel 3 Select switch.
- **4** One by one, touch and move each fader. The other seven faders follow, and the LCD displays resolution for each fader as they move through their range so you can compare fader performance as both a group master and slave.

### **LED Tests**

Use this test to check all LEDs of similar color simultaneously.

#### To test LEDs:

- **1** Press F1 Utility, if necessary, to enter Utility mode.
- **2** Select LED by pressing the channel 3 Select switch. The LCD displays tests for each color LED used in Command|8. Choices include Grn (green), Red, Yel (yellow), and All.
- **3** Select a test by pressing the channel Select switch corresponding to the desired color. To test all LEDs simultaneously, select All. The selected color (or all) LEDs light solid.
- **4** Select another color LED test by pressing its corresponding channel Select switch.
- **5** To exit LED test mode and remain in Utility mode, press channel 8 Select (Exit).
- **6** To exit Utility mode entirely, press F1 Utility.

## **LCD Display Test**

Use this test to assess the performance of the LCD.

#### To test the LCD:

- 1 Press F1 Utility, if necessary, to enter Utility mode.
- 2 Select Disp (Display) by pressing the channel 4 Select switch.
- 3 Press channel 1 Select to start the LCD test. All pixels in the LCD light solid, letting you quickly tell if any area of the display is damaged.
- 4 To turn to all black, press channel 3 Select.
- **5** To exit Display Test mode, press channel 8 Select (Exit).
- **6** To exit Utility mode, press F1 Utility.

## **Switch Test**

Use this test to evaluate the performance of Command 8 switches.

#### To test switches:

- 1 Press F1 Utility, if necessary, to enter Utility mode.
- **2** Select the Switch test by pressing the channel 5Select switch.
- **3** Press any Command 8 switch to test it. The LCD displays the location and name of each switch as you test it.
- 4 To exit Switch test mode, press channel 8 Select (Exit).
- **5** To exit Utility mode, press F1 Utilityl.

## **Encoder Test**

Use this test to evaulate the performance of the Command 8 rotary encoders.

#### To test the encoders:

- 1 Press F1 Utility, if necessary, to enter Utility mode.
- 2 Select Encodr (Encoder) by pressing the channel 6 Select switch.
- 3 Rotate any encoder to test it. Encoder value is displayed in the LCD while testing.
- 4 To exit Encoder test mode, press channel 8 Select (Exit).
- **5** To exit Utility mode, press F1 Utility.

# index

Symbols	C
+4 dBu 11	C 8 Surface 14
@ (inactive send or insert) 39	CC# (Stand-alone mode) 50
	Chan (Stand-alone mode) 50
Numerics	channel controls
-10 dBV 11	faders 22
	mute switch 22
A	Select 22
AC power 9	solo switch 22
A–F	channel select switch 22
plug-ins and inserts 40	Channel View 21
sends 38	switches in stand-alone mode 48
AMS 13	Command 8 system requirements 2
analog 11	top panel 20
Arrow keys	Console View 21
defining selections 33	control room
moving selections up and down 33	connections 11
audio connections 11	control surface targets 3
Avid	Control 24 7
mapping 19	00/10/12 1 1
mode for Command 8 19	D
supported applications 19	dBFS 23
_	
В	Display Mode 23 LCD options 23
Bank 32	LOD OPTIONS 23
bank swapping 3	E
banks 3	<del>-</del>
bypass	Edit 32
plug-ins 41	encoders Stand-alone mode 48
	entering (selecting) 46 Ext Source 11
	EXI Source II

F	K	
F1 Utility 55	knobs (see rotary encoders)	
F2 MIDI Edit 49		
F3 PRE/MIDI Recall 37	L	
F4 Fader Mute 22	LCD	
F5 Focus 28	test 57	
plug-ins 40	LED	
sends 38	MIDI 30	
Fader Flip 23	test 56	
Fader Mute 22	USB 30	
faders 22	Live 45	
muting 22	Loop Record 37	
Stand-alone mode 48 test and reset 56	lost communication 16	
firmware 10, 55	M	
Flip	Main 11	
plug-ins 42	mapping tracks to faders	
sends 39	see Bank and Nudge 32	
focus	Master Faders 23	
plug-ins and targets 40	meters	
footswitch 12	channel LEDs 23	
	pre and post fader 26	
G	using the rotary LEDs 23	
gain (PRE)	mic-pre (see PRE)	
group test 56	MIDI 37	
	CC (Continuous Controller) 45	
Н	configuring AMS 13	
headphones 12	configuring Windows and Macintosh 13	
Home View 21	connections 12	
	continuous controller 45	
I	editing maps in stand-alone mode 49	
In and Out points 33	LED 30 Stand-alone CC assign 50	
inactive	Stand-alone co assign 50 Stand-alone channel assign 50	
display of plug-in status 41	start and end assignments 50	
display of send status 39	SysEx 45	
inserts 26, 40	USB 12	
in Channel View 26	MIDI Control Surfaces	
installation	terminology 3	
guidelines 5	MIDI Machine Control (see MMC)	
-	Mix 32	
	MMC 48, 51	

modes	R	
Flip mode 23	Reason	
operational 19	and Stand-alone mode 45	
Monitor Inputs 11	recording 37	
monitoring	Loop mode 37	
Auto Input and Input Only 36	monitor modes 36	
connections for 11	QuickPunch 35	
using TrackInput 36	TrackPunch 35	
moving selections 33	requirements 2	
multi-mono 42	ReWire 45	
mute	Rewire	
faders 22	see Stand-alone mode	
sends 39	rotary encoders	
mute switch 22	test 57	
N	s	
Nudge 32	scrolling tracks (see Nudge) 32	
	Select 22	
P	sends	
Pages	Flip 39	
presets 47	muting 39	
Pages (plug-ins) 42	viewing and adjusting 38	
Pan/Meter 23	viewing level 23	
Pan/Send/PRE 26	software	
plug-ins 26	and USB ports 10	
Flip 42	solo switch 22	
in Channel View 26	Stand-alone mode 46	
inactive 41	and MMC 48	
multi-mono 42	assigning CC 50	
opening and editing 39	assigning control channel 50	
paging 42	assigning Start and End values 50	
targets and focus 40	compatibility 45	
PRE 37	F2 MIDI Edit mode 49	
enabling MIDI for 15	F3 PRE MIDI Recall 51	
pre and post fader	navigating 47	
metering 26	programmable controls and defaults 48	
presets	programming and editing 49 quickstart instructions 46	
navigating Stand-alone 47	•	
ProControl 7	selecting controls to program 50	
programming	Standby mode 19	
selecting controls 50	Start and End (MIDI) 50	
<b>5</b>	switches	
Q	Stand-alone mode 48	
QuickPunch 35	test 57	
QUICKE UIICH 33	SysEx 45	
	system requirements 2	

T	V
target	ventilation 5
and control surfaces 3 and plug-in windows 40	view options 23 views
test	Channel View 21
LCD 57 LEDs 56	Console View 21
rotary encoders 57	F5 focus 40 Home View 21
switches 57	Home view 21
TrackInput monitoring 36	w
TrackPunch 35	Web site 2
tracks	Windows
banking 32	Edit 32
metering 23	Mix 32
scrolling 32 Transport	Plug-In 32
and MMC 48	
switches in stand-alone mode 48	Z
troubleshooting 16	Zoom 32
	zoom controls 28
U	
Up and Down 33	
USB 9	
and AMS 13	
LED 30	
MIDI 12	

port limitations 10