

Studio Tube Microphone Preamp

Channel One

Channel Two

Channel One controls:

- PHANTOM POWER**: +48V switch
- INPUT PAD**: NORM (-30dB) and -30dB switches
- LINE INPUT**: Input selector
- GAIN**: Knob with markings at +38 dB and +65
- VOLUME**: Knob with markings at -∞ dB and 0

Channel Two controls:

- PHANTOM POWER**: +48V switch
- INPUT PAD**: NORM (-30dB) and -30dB switches
- LINE INPUT**: Input selector
- GAIN**: Knob with markings at +38 dB and +65
- VOLUME**: Knob with markings at -∞ dB and 0



CHANNEL ONE

CHANNEL TWO

Bellari

RP520

